

MONTREAL (P.E Trudeau) (YUL/CYUL)

Elevation 118ft

CATEGORY A

AV brief – not required

GENERAL

- Local traffic may be controlled in French.

Threats

CFIT

- Obstruction Mt Royal, 1199ft amsl, 5.5 nm ENE of airfield.

Loss of Control

- Hazardous high speed wind tunnel exhaust approx 0.5 nm SSE of Threshold 24L. May cause mechanical turbulence and heat from Surface to 1000ft agl.

Runway Incursion

- Arriving Rwy 06R or departing Rwy 24L requires crossing of Rwy 10/28 on Twy A.
- When cleared via Twy A for Rwy 24L departure, exercise caution at HS5 to avoid taxi along Twy A4 towards Rwy 06R/24L. Markings and signage are reported as difficult to see with poor lighting.

ARRIVAL

Diversions Airports

OTTOWA	YOW/CYOW	082 nm/264°T	CAT A
BOSTON	BOS/KBOS	221 nm/148°T	CAT B
TORONTO	YYZ/CYYZ	274 nm/247°T	CAT A
NEW YORK	JFK/KJFK	290 nm/180°T	CAT B

Others that may be used include Philadelphia, Washington, Newark, Baltimore and Bangor.

GROUND

- ATC advise that when exiting a runway, unless otherwise instructed, pilots should continue to taxi forward across the taxi holding position lines or to a point at least 200 feet from the edge of the runway, where a taxi holding position line is not available, before calling clear of the runway.
- Following closure of the satellite terminal, BAV crews can now expect stand allocation within the new ramp to the west of the main terminal. Please note that entry to this ramp is approved only via the Centre taxiway as wingtip clearance cannot be assured on the Left or Right taxiways.
- See Lido Ground Charts for Low Vis Taxi Charts.

WEATHER

- Nov – Apr: Snow averages 15-20 inches per month, usually deposited by fast moving W to E depressions.
- May – Oct: Generally good conditions, sunny, hot and occasionally muggy.
- Fog occurs in Spring and Autumn.

OPERATIONAL INFORMATION

Handling Agent	BA-CUST SVC/SWISSPORT-RAMP
Handling Agent VHF	129.6
Potable Water	Uplift permitted

IF ONLY Electrical Power is required	Use ground power at all times
If BOTH electrical power and air conditioning is required:	Use both ground services at all times